

INSTRUKCJA MONTAŻU I EKSPLOATACJI ZACZEPU KULOWEGO DO SAMOCHODU:

Mazda Tribute (03/2004 -)

Ford Maveric (02/2004 -)

Nr kat. M-050

PRZEZNACZENIE

Zaczepek kulowy **M-050** jest przeznaczony do holowania przyczepy. Zaczepek ten posiada aktualne Świadectwo Homologacji uprawniające do oznaczenia wyrobu znakiem homologacji **e20**.

WARUNKI MONTAŻU

Zaczepek kulowy **M-050** może być używany i eksploatowany w samochodzie o właściwym stanie technicznym elementów nadwozia. Zaczepek musi być zamontowany i eksploatowany w samochodzie zgodnie z niniejszą instrukcją.

Wszystkie śruby i nakrętki występujące w zaczepek kulowym muszą być dokręcone odpowiednim momentem obrotowym (M_o) o wartościach podanych w poniższej tabeli (dla śrub w klasie 8.8):

M8	-	25 (Nm)	M12	-	85 (Nm)
M10	-	50 (Nm)	M16	-	200 (Nm)

WARUNKI EKSPLOATACJI

Zaczepek kulowy **M-050** posiada tabliczkę znamionową określającą prawidłowe i bezpieczne obciążenie zaczepeku, tj.:

Typ: M-050	Numer katalogowy zaczepeku kulowego
A50-X	Klasa zaczepeku kulowego (urządzenia sprzęgającego)
e20 00-1556	Nr świadectwa Homologacji zaczepeku kulowego
D = 10,0 kN	Teoretyczna siła odniesienia działająca na zaczepek kulowy
S = 80 kg	Max. dopuszczalne obciążenie pionowe kuli zaczepeku
R = 2000 kg	Max. dopuszczalne obciążenie holowanej przyczepy

Siłę D wylicza się ze wzoru:

$$D = g \times \frac{T \times R}{T + R} \text{ kN}$$

T-technicznie dopuszczalna maksymalna masa, w tonach, pojazdu ciągnącego (także ciągników holujących) łącznie, jeśli występuje, z obciążeniem pionowym przyczepy z osią centralną.

R-technicznie dopuszczalna maksymalna masa, w tonach, przyczepy samochodowej z dyszlem ruchomym w płaszczyźnie pionowej lub naczepey.

g- przyspieszenie ziemskie (przyjmowane jako 9,81 m/s²)

Podczas eksploatacji poszczególne elementy zaczepeku kulowego powinny być utrzymane w należytych stanie technicznym i zabezpieczone przed działaniem korozji. W czasie holowania przyczepy musi być złączona dodatkowym elastycznym złączem o odpowiedniej wytrzymałości (linka, łańcuch). W czasie eksploatacji zaczepeku kulowego należy okresowo sprawdzać połączenia śrubowe, a w przypadku poluzowania nakrętek należy je dokręcić.

MONTAŻ

Zaczepek kulowy **M-050** składa się z następujących elementów:

1. Korpus	- 1 szt.	13. Podkładka sprężysta Ø5,1	- 2 szt.
2. Kula	- 1 szt.	14. Podkładka sprężysta Ø8,2	- 2 szt.
3. Uchwyt do gniazda elektrycznego	- 1 szt.	15. Podkładka sprężysta Ø10,2	- 2 szt.
4. Wspornik prawy	- 1 szt.	16. Podkładka sprężysta Ø12,2	-12 szt.
5. Wspornik lewy	- 1 szt.	17. Podkładka okrągła Ø5,3	- 4 szt.
6. Płaskownik	- 2 szt.	18. Podkładka okrągła Ø8,4	- 4 szt.
7. Kątownik	- 2 szt.	19. Podkładka okrągła Ø10,5	- 2 szt.
8. Śruba M5x20 (PN/M-82105)	- 2 szt.	20. Podkładka okrągła Ø13,0	- 8 szt.
9. Śruba M8x25 (PN/M-82105)	- 2 szt.	21. Nakrętka M5	- 2 szt.
10. Śruba M10x25 (PN/M-82105)	- 2 szt.	22. Nakrętka M8	- 2 szt.
11. Śruba M12x40 (PN/M-82105)	-10 szt.	23. Nakrętka M12	- 6 szt.
12. Śruba M12x65 (PN/M-82101)	- 2 szt.		

30.10.2015.

Nr kat. M-050

W celu zamontowania zaczepeku kulowego należy przestrzegać poniższego opisu:


1. Montaż zaczepeku **wymaga demontażu i podcinania** zderzaka tylnego samochodu.
2. Zdemontować zderzak tylny wraz ze wzmocnieniem i wypełnieniem plastikowym. Wkręcić fabryczne nakrętki na wystające szpilki w miejscach mocowania wzmocnienia (wzmocnienie nie będzie ponownie wykorzystane).
3. Z lewej strony samochodu zdemontować uchwyt, do którego doczepione jest gniazdko elektryczne (odczepić gniazdko, uchwyt nie będzie ponownie montowany). Dwie śruby mocujące uchwyt ponownie wkręcić do samochodu.
4. Odgiąć wystające elementy wewnątrz podłużnic samochodu celem udrożnienia miejsc montażowych zaczepeku.
5. Wsunąć wsporniki (4 i 5) do wewnątrz podłużnic, przyłożyć z drugiej strony płaskowniki (6) i skrócić śrubami M12x40 (11) wraz z podkładkami sprężystymi Ø12,2 (16).
6. Pomiędzy zamontowane wsporniki (4 i 5) wsunąć korpus (1) i skrócić śrubami M12x40 (11) wraz z podkładkami okrągłymi Ø13,0 (20), podkładkami sprężystymi Ø12,2 (16) i nakrętkami M12 (23).
7. Dokręcić korpus (1) do spodu samochodu śrubami M10x25 (10) wraz z podkładkami sprężystymi Ø10,2 (15) i podkładkami okrągłymi Ø10,5 (19). Do korpusu (1) dokręcić kątowniki (7) śrubami M8x25 (9) wraz z podkładkami okrągłymi Ø8,4 (18), podkładkami sprężystymi Ø8,2 (14) i nakrętkami M8 (22).
8. Na belkę poprzeczną zaczepeku położyć wypełnienie plastikowe zderzaka i przymocować do belki przy pomocy opasek zaciskowych. Z gniazdkiem elektrycznym postąpić podobnie.
9. Wykonać podcięcie w zderzaku według załączonego rysunku: (1) Mazda Tribute lub (2) Ford Maverick.
10. Zamontować zderzak do samochodu (od spodu zderzak przykręcić dwoma śrubami M5x20 (8) wraz z podkładkami okrągłymi Ø5,3 (17), podkładkami sprężystymi Ø5,1 (13) i nakrętkami M5 (21).
11. Do korpusu (1) dokręcić kulę (2) i uchwyt gniazda elektrycznego (3) śrubami M12x65 (12) wraz z podkładkami okrągłymi Ø13,0 (20), podkładkami sprężystymi Ø12,2 (16) i nakrętkami M12 (23).

Przestrzeganie niniejszej instrukcji zapewnia prawidłowy montaż i eksploatację zaczepeku kulowego M-050.

Po zamontowaniu zaczepeku kulowego **M-050** należy uzyskać wpis w **dowodzie rejestracyjnym** pojazdu.

UWAGA: Sprawdzać połączenia śrubowe po przejechaniu 1000 km. Kulę zawsze utrzymywać w czystości i smarować smarem stałym. Stosować osłonę kuli. Wszystkie uszkodzenia mechaniczne zaczepeku kulowego **M-050** wykluczają dalszą jego eksploatację. Uszkodzony zaczepek **nie może być naprawiany**. W przypadku nie przestrzegania opisanego sposobu montażu lub niewłaściwego jego użytkowania producent **nie ponosi odpowiedzialności** za powstałe szkody.

SCHEMAT MONTAŻU:



UWAGA:

Cena zaczepeku kulowego nie obejmuje wiązki elektrycznej.

Nr kat. M-050

TOW BAR FOR Mazda Tribute (03/2004 -) Ford Maveric (02/2004 -) FITTING AND OPERATION MANUAL.

Cat. No.M-050

DESTINATION

Tow bar **M-050** is designed for towing a trailer. This ball hook has a current certification of approval authorizing the product with **e20** certification sign.

FITTING CONDITIONS

Tow bar **M-050** can be used and operated in a car with proper technical conditions of body elements. Those parts cannot be mechanically damaged. The ball hook has to be installed and operated in a car according to this instruction. All bolts and nuts in ball hook have to be screwed down with proper torque (Mo). Torque values are given below:

M8	-	25 (Nm)	M12	-	85 (Nm)
M10	-	50 (Nm)	M16	-	200 (Nm)

OPERATION CONDITIONS

The tow bar **M-050** has a rating plate describing correct and safe loads of the hook:

Typ: M-050	Tow bar catalogue number.
A50-X	Tow bar class (compressing device)
e20 00-1556	Tow bar certification of approval number
D = 10,0 kN	Teoretical related force working on a ball hook
S = 80 kg	Max permissible vertical load of the hook ball
R = 2000 kg	Max permissible load of towing trailer

D - force is calculated using the following formula:

$$D = g \times \frac{T \times R}{T + R} \text{ kN}$$

T-technically permissible maximum mass in tonnes of the towing vehicle (also towing tractors) including, if necessary, the vertical load of a centrale axle trailer.
R-technically permissible maximum mass in tonnes of the full trailer with drawgal free to move in the vertical plane or of the semi-trailer.
g-acceleration due to gravity(assumed as 9,81 m/s²)

During operating individual elements of ball hook should be kept in a proper technical condition and protected from corrosion. The trailer must be linked with an elastic joint with proper durability (cord, chain) while towing. It is necessary to check periodically bolt joints during operating the ball hook. If screws are eased, it is necessary to screw them down.

FITTING

The tow bar **M-050** is made up of the following elements:

1. Towbar mainframe	- 1 piece	13.Spring washer Ø5,1	- 2 pieces
2. Tow ball	- 1 piece	14.Spring washer Ø8,2	- 2 pieces
3. Electrical socket plate	- 1 piece	15.Spring washer Ø10,2	- 2 pieces
4. Right support	- 1 piece	16.Spring washer Ø12,2	-12 pieces
5. Left support	- 1 piece	17.Flat washer Ø5,3	- 4 pieces
6. Flat bar	- 2 pieces	18.Flat washer Ø8,4	- 4 pieces
7. Angle bar	- 2 pieces	19.Flat washer Ø10,5	- 2 pieces
8. Screw M5x20	- 2 pieces	20.Flat washer Ø13,0	- 8 pieces
9. Screw M8x25	- 2 pieces	21.Nut M5	- 2 pieces
10. Screw M10x25	- 2 pieces	22.Nut M8	- 2 pieces
11. Screw M12x40	-10 pieces	23.Nut M12	- 6 pieces
12. Screw M12x65	- 2 pieces		

Please follow the installation fitting instruction below in order to ensure correct installation of the towbar:

1. Rear bumper cutting and removing is required.
2. Remove the rear bumper with it strengthening and plastic filling. Screw the factory nuts on the protruding pins at points of strengthening attachment (strengthening will not be reused).
3. Remove holder from the left side to which is attached tow ball socket (remove the socket, the holder will not be reused). Two fixing screws screw again to the car.
4. Bend the protruding elements inside of the stringers to unblocking the mounting points.
5. Insert the supports (4 and 5) to the inside of stringers, attach from the other side flat bars (6) and screw on using bolts M12x40 (11) with spring washers Ø12,2 (16).
6. Between two mounted supports (4 and 5) slide the corps (1) using bolts M12x40 (11) with flat washers Ø13,0 (20), spring washers Ø12,2 (16) and nuts M12 (23).
7. Attach the corps (1) to the bottom of car using bolts M10x25 (10) with flat spring washers Ø10,2 (15), and flat washers Ø10,5 (19). Tighten angles (7) to the corps (1) using bolts M8x25 (9) with flat washers Ø8,4 (18), spring washers Ø8,2 (14) and nuts M8 (22).
8. Put the bumper's plastic filling on the hitch crossbar and attach to the beam using clamp. With electrical socket do the same.
9. Perform undercut in the rear bumper according to the attached drawings: (1) - Mazda Tribute, or (2) - Ford Maverick.
10. Install the rear bumper to the car (screw on the rear bumper to the car using two bolts M5x20 (8) with flat washers Ø5,3 (17), spring washers Ø5,1 (13) and nuts M5 (21).
11. Attach the tow ball (2) and electrical plate (3) to the corps (1) using bolts M12x65 (12) with flat washers Ø13,0 (20), spring washers Ø12,2 (16) and nuts M12 (23).


Obeying this instruction assures correct montage and the M-050 tow bar operating.

After assembling of the tow bar **M-050** you have to get entry in cars **registration book**.

CAUTION:

Check if all bolts and nuts are correctly tightened after 1000km. Keep tow ball clean, grease and cased. All mechanical damages of tow bar excludes its further exploitation. Damaged ball hook **cannot be repaired**. In case of braking the rules of montage or improper usage manufacturer **do not take responsibility** for arised damages.

MONTAGE DIAGRAM:



NOTE:

Bunch of wires is not included (in total price).